

On behalf of all of us here at:



THANK YOU FOR YOUR PURCHASE!

Dear Woodworkers,

We appreciate your interest in Multiple Layer inlay Stencils. We believe that we provide a simple way to create high quality inlays over and over, for an affordable price using our stencils. While we are confident in our stencils, we always value your feedback to help us create designs that you want to use so please let us know what you think in the contact us section. Also, on the contact us page be sure to send us a picture of your finished inlay along with a word or two about the piece, and we would love to show it off on our site for everyone to see. For any additional questions, or support please send us an email at: TarterWoodworking@TarterWoodworking.com

Like us on Facebook via the website homepage to get updates on special events, pricing, and new design releases!

Thanks Again,

Tarter Woodworking LLC

Additional Instructions: YIN YANG

***FOR A DETAILED 10 MINUTE INSTRUCTIONAL VIDEO ON “HOW TO CREATE AN INLAY USING A MULTIPLE LAYER INLAY STENCIL”, PLEASE VISIT THE “HOW TO” SECTION OF THE WEBSITE: WWW.TARTERWOODWORKING.COM.

However this particular design does require some additional instructions besides the basics available in the above mentioned video...

1. Some parts for this inlay need to be cut in thicker material and re-sawn out, because of their small size. (Small circles on plate#3)
2. For clarity, directions are to recreate with the same woods as the display. However you can use any type of wood that you like. The thing that makes every inlay special is finding the perfect color or wood grain to accentuate the design.

Step 1 Cut your inlay pieces. Be sure that the collar is removed from your 1/8 In. inlay kit.

Cut plate #1 from Quarter sawn Sycamore 1/4 In. thick. Be sure not to bottom out the bit into the inlay kit.

Note: Be sure to mark orientation of this piece with an arrow pointing to the top this will make a better fit when inserting the inlay.

Cut plate#2 from Wenge' 1/8 In. thick

Cut plate#3 top hole Wenge' 1/8 In. thick. Bottom hole Quarter sawn Sycamore.

Step#2 Set up positioning plates on your project piece. Be sure collar is installed on the inlay kit. Using plate #1 rout out the pocket. Remove plate and glue inlay in place, let dry then sand flush.

Step#3 Follow directions in step#2 for remaining plates in numerical order.