

On behalf of all of us here at:



THANK YOU FOR YOUR PURCHASE!

Dear Woodworkers,

We appreciate your interest in Multiple Layer inlay Stencils. We believe that we provide a simple way to create high quality inlays over and over, for an affordable price using our stencils. While we are confident in our stencils, we always value your feedback to help us create designs that you want to use so please let us know what you think in the contact us section. Also, on the contact us page be sure to send us a picture of your finished inlay along with a word or two about the piece, and we would love to show it off on our site for everyone to see. For any additional questions, or support please send us an email at: *TarterWoodworking@TarterWoodworking.com*

Like us on Facebook via the website homepage to get updates on special events, pricing, and new design releases!

Thanks Again,

Tarter Woodworking LLC

Additional Instructions: 4" Butterfly

***FOR A DETAILED 10 MINUTE INSTRUCTIONAL VIDEO ON "HOW TO CREATE AN INLAY USING A MULTIPLE LAYER INLAY STENCIL", PLEASE VISIT THE "HOW TO" SECTION OF THE WEBSITE: WWW.TARTERWOODWORKING.COM.

However this particular design does require some additional instructions besides the basics available in the above mentioned video...

1. For clarity, directions are to recreate with the same woods as the display. However, you can use any type of wood for each inlay piece that you prefer. After all, it is the color and grain in the wood that makes every inlay uniquely special.
2. With the 4" Butterfly, picking out a great piece of wood is of greatest importance. Look for some very nice figure or even a Burl. You will want your wings to match so butterfly cut your wood and cut your inlays from the matching wood.

Step 1:

Cut out your inlay pieces. Be sure that the collar is removed from your 1/8 In. inlay kit.

Cut plate #1 from Parotwood 1/8" In. thick. Cut bottom right wing and then flip plate over to cutout the bottom left wing.

Cut plate #2 from Parotwood 1/8 In. thick. Cut upper right wing and then flip plate over to cutout upper left wing.

Cut plate #3 from Wenge' 1/8 in. thick.

Step 2:

Install the collar on the inlay kit. Position plate 1-3 to rout out the pocket for the right lower wing. Glue inlay in place. Let dry and sand flush. Turn plate 1-3 over to complete lower left wing.

STEP 3:

Using plate 2-3 complete as above.

Step 4:

Using a pencil, sketch the placement of the antenna. Using a chisel, create a groove along the antenna approx. 1/16" deep. Back cut groove with exacto knife.

**Use masking tape over porous wood before applying glue.

Mix Wenge' dust and glue at 1:1 ratio and apply heavily to groove. Be sure to apply excessive dust glue mixture to make up for glue contraction when it dries.

**If you used tape, remove it before the glue sets up in the groove.

When Dry, Sand flush.

Step 5: Use plate 3-3 to rout out pocket for body. Glue in inlay and sand flush.