On behalf of all of us here at:



## THANK YOU FOR YOUR PURCHASE!

Dear Woodworkers,

We appreciate your interest in Multiple Layer inlay Stencils. We believe that we provide a simple way to create high quality inlays over and over, for an affordable price using our stencils. While we are confident in our stencils, we always value your feedback to help us create designs that you want to use so please let us know what you think in the contact us section. Also, on the contact us page be sure to send us a picture of your finished inlay along with a word or two about the piece, and we would love to show it off on our site for everyone to see. For any additional questions, or support please send us an email at: *TarterWoodworking@TarterWoodworking.com* 

Subscribe to our newsletter to find out about new designs when they become available as well as exclusive subscriber discounts.

Like us on Facebook via the website homepage to get updates on special events, pricing, and new design releases!

Thanks Again,

Tarter Woodworking LLC

## Instructions: 4 IN CROSS

\*\*\*FOR A DETAILED 10 MINUTE INSTRUCTIONAL VIDEO ON "HOW TO CREATE AN INLAY USING A MULTIPLE LAYER INLAY STENCIL", PLEASE VISIT THE "HOW TO" SECTION OF THE WEBSITE: <u>WWW.TARTERWOODWORKING.COM</u>. Here, you can also access detailed printable .pdf instructions for each M.L.I.S. design.

Additional Instructions:

- 1. Any piece smaller than 1" in diameter should be re-sawn or sanded from a thicker timber.
- 2. The 4 IN CROSS can be completed as a normal inlay following the general directions, Start with plate 1 and work thru the plates in order to complete the inlay.
- 3. In addition you can complete as an inlaid inlay. To do this cut out your inlay pieces for plates 2 thru 4. Then set up your positioning plates on the material you wish to be the outside edge, which is thicker than your inlay pieces. In the display inlay we used Wenge'. Complete the inlay process using plates 2 thru 4. Now use plate 1, with the Collar removed from the inlay kit cut

deeper than the pieces previously inlayed. Using the bit provided with your inlay kit you can only cut ¼ in deep. (if you wish to go thicker an extended length bit is available on the website) Then resaw the entire inlay out. Use plate 1 with the collar on your inlay kit installed to inlay on your project.

4. Using the above method you can complete as an intarsia style inlay by just cutting your pocket shallower than your inlay. The top edges can be rounded by sanding or as in the display we used a dremel with a router base and a 1/8 in roundover bit before resawing the inlay out.