

On behalf of all of us here at:



THANK YOU FOR YOUR PURCHASE!

Dear Woodworkers,

We appreciate your interest in Multiple Layer inlay Stencils. We believe that we provide a simple way to create high quality inlays over and over, for an affordable price using our stencils. While we are confident in our stencils, we always value your feedback to help us create designs that you want to use so please let us know what you think in the contact us section. Also, on the contact us page be sure to send us a picture of your finished inlay along with a word or two about the piece, and we would love to show it off on our site for everyone to see. For any additional questions, or support please send us an email at: TarterWoodworking@TarterWoodworking.com

Subscribe to our newsletter to find out about new designs when they become available as well as exclusive subscriber discounts. Like us on Facebook via the website homepage to get updates on special events, pricing, and new design releases!

Thanks Again,

Tarter Woodworking LLC

Instructions: **Compass Rose**

***FOR A DETAILED 10 MINUTE INSTRUCTIONAL VIDEO ON "HOW TO CREATE AN INLAY USING A MULTIPLE LAYER INLAY STENCIL", PLEASE VISIT THE "HOW TO" SECTION OF THE WEBSITE:

WWW.TARTERWOODWORKING.COM. Here, you can also access detailed printable .pdf instructions for each M.L.I.S. design.

Additional Instructions:

The Compass Rose is a rotational design. And unlike the general directions the pockets are numbered instead of the plates. Simply complete all pockets in numerical order.

The points of the Compass Rose can be done as a single color by simply following the general directions, to achieve the two tone look of the display you will need to do a glue up of two contrasting woods. It is recommended that you use 1/8 in or thicker wood, if using thicker wood re-saw to the desired thickness on a band saw or table saw.

Step 1 Cut four inlay pieces for each pocket with the collar removed from your inlay kit. If using the two toned glue ups simply align the engraved center line on your plate with the glue joint. It is very

important that your router is in the same orientation now as when you cut your pocket later, so mark your pieces with an arrow to know which side is up and your orientation for cutting the pocket.

Step 2 Use the engraving on the plates to position where you want your inlay on your project. Then apply positioning plates with double sided tape.

Step 3 Reinstall the collar on your inlay kit. You can only inlay two pieces for each pocket at a time because of the overlap. So cut a pocket with the top of the plate flush against the top positioning plate for pocket number 1 only. Then rotate so the bottom is flush and cut that pocket number 1 only. Glue in your inlay pieces then let them dry and sand flush. Now cut pockets with each side flush against the top positioning plate. Glue in your inlay pieces then let dry and sand flush.

Step 4 Repeat the procedure above for pocket number 2.

Step 5 Repeat the procedure above for pocket number 3 to complete your inlay.